

TECHNICAL DATA SHEET

MARBOCOTE HP2002



Product Description: HP2002 Tool Sealer is designed to seal all types of highly porous substrates. HP2002 is a one component high solids moisture cure system in a solvent carrier that gives a high gloss finish to the surface.

Recommended Uses: HP2002 can seal highly porous substrates such as epoxy and polyurethane tooling board, MDF, gelcoated and non-gelcoated polyester and epoxy composite moulds.

Product Benefits:
High sealing capability
High gloss without polishing
Fast cure
Non-contaminating
Quick and easy to apply

Product Characteristics:	
Appearance	Clear colourless liquid
Composition	Aliphatic hydrocarbon, Disobutyl ketone, Methanol
Flash Point	<10°C
Application Temperature	Ideal temperature 15°C - 30°C
Thermal stability of cured film	250°C
Coverage	20 - 50 m ² / L per coat
Application Type	Wipe or Spray
Shelf Life	6 months

Note: The polymeric resin used in HP2002 Tool Sealer reacts with moisture. Please ensure can is resealed immediately after use.

Please read Safety Data Sheet before use. Do not mix with other products or solvents. Application should be conducted in a dust free area with good ventilation. Solvent resistant gloves and eye protection must be worn during this process.

The number of coats of HP2002 Tool Sealer required depends on the porosity of the surface and the amount applied with each coat. Due to variations in application technique and to the large range in porosity observed in mould and tooling systems, prior to using HP2002 Tool Sealer in a production environment it is important that the user determine for themselves how many coats are required to adequately seal the type of substrate being coated.

A superior finish can be obtained by flattening back the surface before applying the final 1 or 2 coats. The coating needs to be cured for at least 2 hours at room temperature (or 15min at 60°C) for sanding or polishing to be possible.

HP2002 Tool Sealer must be used in conjunction with an appropriate release agent, such as Marbocote HP7. Marbocote HP7 is specifically designed to be applied on top of Marbocote HP Tool Sealers; see HP7 Technical Data Sheet for more details.

Mould Cleaning: This needs to be performed prior to product application

Ensure that the mould or tool surface is cleaned with Marbocote Mould Cleaner to remove traces of dust, dirt, oils or release agent. The mould must be clean and dry before use.

Application Type: For a superior gloss finish, wipe application is preferred. For the best finish, it is important that the coating procedure be performed in a dust free environment and using lint free cloths. HP2002 can also be brush applied in a similar manner to this application. The use of foam brushes ("Jenny" brushes) has been found to give particularly good results.

When spraying, the use of a High Volume Low Pressure (HVLP) spray gun is strongly recommended. This type of spray gun will give the best drying pattern and highest gloss finish while providing optimum transfer efficiency.

Marbocote Ltd

Unit 9, Dalton Way, Middlewich
Cheshire, CW10 0HU, UK

Tel: +44 (0)1606 738737

Email: info@marbocote.co.uk

Registered in England & Wales No. 04275657 | Registered office: Unit 9, Dalton Way, Middlewich, Cheshire, CW10 0HU

www.marbocote.co.uk

Wipe/Brush Application Technique:

- 1) To apply Marbocote HP2002 you need a clean, dry lint free cloth. The choice of cloth is important; as the HP2002 resin reacts with water, the cloth must be dry. A smooth, soft cloth with a high synthetic content such as Kimberly Clark Wypall™ X60, Dupont Sontara EC™ or microfibre cloths is ideal.
- 2) Fold the cloth so that a smooth, flat surface is presented to the mould surface; ensure that all areas of the cloth are coated with product.
- 3) Wipe the wet cloth over mould surface covering an area of approximately 0.2m². Vigorous rubbing or polishing is not required. Frequently re-wet the cloth to ensure a complete wet film is formed on substrate surface.
- 4) Repeat step 3 on the adjacent area, frequently reapplying the product to the cloth. Take care to minimize the overlap area where previously applied product has dried but not cured sufficiently.
- 5) Repeat until mould is completely coated. Change the cloth if it becomes dirty.
- 6) When applying to relatively non-porous surfaces (such as carbon composite), allow at least 20 minutes at room temperature between coats. For highly porous surfaces, such as MDF and tooling board, repeat Steps 1-5 above allowing only 2-3 minutes between coats to allow for solvent evaporation. When the HP2002 builds-up sufficiently, the board will start to obtain a gloss finish; at this point, the 20 minutes between coats will be required to ensure a high gloss finish is maintained.
- 7) Reapply product until the mould is sealed (i.e. a gloss surface starts to become evident). This can vary from only 1 to 2 coats for composite moulds to 8 – 12 coats for highly porous tooling board. See *NOTE* above.
- 8) Once the mould or tool is sealed, then the coating needs to be cured. See “Cure Times” table below.
- 9) Apply release agent top-coat (e.g. Marbocote HP7; see HP7 Data Sheet for more details).

Spray Application Technique:

Spray Gun Parameters	
Air pressure	2-2.5 bar (30-35 psi)
Fluid needle size	<1.2mm
Distance from mould	20cm
Film dry time	5 minutes

Note: Ensure that you apply light uniform coats and the product is not running or dripping (especially on vertical surfaces). It is important to clean the Spraygun immediately after use with acetone or similar to ensure that the product doesn't fully cure in the gun.

- 1) Holding the nozzle of the gun approximately 20cm from the mould surface, adjust the output so that the product forms a very light coating on the surface.
- 2) Systematically coat the entire surface of the mould. Care must be taken to over-lap sprayed areas.
- 3) Allow the product to dry (typically approx. 5 minutes at 20°C) before applying the next coat. Apply each coat at 90° to the previous.
- 4) Depending on the porosity of the substrate, repeat Steps 1-3 above until the mould is sealed (typically 1 coat for composite surfaces, 4-6 coats for tooling board). See *NOTE* above.
- 5) Once the mould or tool is sealed then the coating needs to be cured. See “Cure Times” table below.
- 6) Apply release agent top-coat (e.g. Marbocote HP7; see HP7 Data Sheet for more details).

Cure Times:

Temp (°C)	Cure Time
Room temp (20°C)	2 hours
60°C*	15 minutes

* If heating, allow sufficient time for the mould to reach temperature (i.e. adjust cure time to compensate for mould or tool mass). Note: depending on mould configuration and room environment (temperature and humidity), the HP2002 Tool Sealer may also require a longer cure than detailed above.

After application of the Sealer, a release agent top-coat (such as Marbocote HP7), is required before starting production. The efficiency of the final release film is best determined through a combination of tape tests and experimentation.

Issue 8

Note: The user will determine the suitability for use of this product. The recommendations / data given above are based on information we believe to be accurate. They are intended to be used only as a guide for selection for end-use evaluation and do not constitute a product specification. Marbocote cannot assume responsibility for results obtained by use of this product as we have no control over end-use applications or handling. Marbocote therefore specifically disclaims any damage or loss of any kind in relation to the use of this product.